



ALLIED PRESSROOM PRODUCTS

PRODUCT INFORMATION

10209

POSITIVE DEVELOPER POWDER

Product Overview

Designed for use with most commercially available presensitized positive working printing plates. Fast acting, leaves a clean background and preserves image contrast.

Recommendations for Use

To Prepare a 4:1 Developer Concentrate:

Dissolve 2 Lb of Positive Developer Powder in 1 gallon of clean water. Use caution when handling the material in powder form as it is corrosive on skin contact. Wear protective gloves and goggles.

To prepare a Ready to Use Developer Solution:

Dilute one part of concentrate with four parts of water.

Manual Plate Development:

Pour sufficient developer solution onto the plate surface to ensure thorough coverage. Using a lint free cotton wipe, or developing pad, rub gently using a circular action. Ensure the whole plate surface is treated and that the emulsion is dissolved before adding a further amount of fresh developer. Complete the process by gently rubbing to remove last traces of emulsion from the background. Rinse with running water and wipe down using a fresh pad. The plate is ready to run. If the plate is not being run immediately, apply a coating of finishing gum to preserve the water receptivity of the non-image area.

Processors:

Follow the processor manufacturers' recommendations regarding quantity to add, set temperature to 75°F. Ensure all rollers are clean and set pressures according to specification, change filters regularly to ensure longer developer life and better performance.

WORLDWIDE MANUFACTURING & TECHNICAL SUPPORT

ALLIED PRESSROOM PRODUCTS

CORPORATE: 2040 LEE STREET / HOLLYWOOD, FL 33020
PH: 954-920-0909 FAX: 954-923-6462

CALIFORNIA: 3546 EMERY STREET / LOS ANGELES, CA 90023
PH: 323-266-6250 FAX: 323-266-4382



ABC CHEMICAL Co.

ENGLAND: PH: +44 1200420180 FAX: +44 1200426178

ABC-ALLIED PRESSROOM PRODUCTS

CHINA: PH: +86 755 2769 2368 FAX: +86 755 2769 2298