



# Inking Roller Care Program

Ensure wet ink has been removed then start with STEP 1

## STEP 1: TO REMOVE INGRAINED CONTAMINANTS AND DEGLAZE

Apply **DYNAKLEAN** roller paste to top inking roller and allow press to idle for up to 5 minutes.

Wash up roller train using normal technique and press wash

Finish this step with a water rinse and back off the wash up device

## STEP 2: TO REMOVE CALCIUM AND SURFACTANT RESIDUES

Apply a liberal amount of **RELIEF** to the rollers

Allow the press to idle for up to 5 minutes applying more as necessary to keep the rollers wet

Bring wash up device into contact and rinse with water

## REPEAT THIS PROCEDURE ON A WEEKLY BASIS

**THE INKING ROLLERS ARE NOW CLEAN & CONTAMINANT FREE**

ALLIED PRESSROOM PRODUCTS.....FL. USA  
PH: 954-920-0909 FAX: 954-923-6462

ALLIED LITHO PRODUCTS.....CA. USA  
PH: 323-266-6250 FAX: 323-266-4382



ABC CHEMICAL CO LTD.....ENGLAND  
PH: +44 1200420180 FAX: +44 1200426178

ABC-ALLIED PRESSROOM PRODUCTS.....CHINA  
PH: +86 755272386 FAX: +86 75527692298